


1 1 1



NOTE - TIE BARS MUST BE INSTALLED FOR MAXIMUM UNIT STRENGTH.

ONE TIE BAR PER LEVEL FOR FOUR AND FIVE FOOT WIDTH. TWO TIE BARS PER LEVEL FOR SIX AND EIGHT FOOT WIDTH.

## 'V' GRIP RACK ASSEMBLY INSTRUCTIONS

- STEP 1. STAND ONE RACK END VERTICALLY. NOTE THAT LARGER PORTION OF UPRIGHT SLOTS ARE TOWARD THE TOP. (SEE FIG. 1 & 1A.)
- STEP 2. INSERT HOOKS ON END OF ONE CROSS BEAM INTO SLOTS IN RACK END

  UPRIGHT AT LOWEST LEVEL AND PUSH DOWN. (SEE FIG. 1B.) REPEAT

  THIS SAME PROCEDURE WITH 2ND CROSS BEAM AT THE OPPOSITE UPRIGHT

  OF THE SAME RACK END. (SEE FIG. 1.) BE SURE CROSS BEAMS HAVE THE

  SAME WEIGHT CARRYING CAPACITY AND ARE INSTALLED AT THE SAME HEIGHT

  IN BOTH UPRIGHTS.
- STEP 3. STAND ANOTHER RACK END VERTICALLY BUT WITH THE DIAGONAL BRACING
  RUNNING IN THE OPPOSITE DIRECTION FROM THE FIRST RACK END. INSERT
  HOOKS ON THE OPPOSITE ENDS OF THE TWO PARTIALLY ASSEMBLED CROSS
  BEAMS INTO CORRESPONDING SLOTS IN THE 2ND RACK END. (SEE FIG. 2.)
- STEP 1. INSTALL REMAINING CROSS BEAMS INTO RACK BY HOOKING BOTH ENDS OF
  EACH CROSS BEAM INTO UPRIGHT SLOTS OF BOTH RACK ENDS. BE SURE EACH
  BEAM IS PARALLEL WITH THE FLOOR AND EACH PAIR OF BEAMS IS LOCATED
  AT THE SAME HEIGHT ON THE RACK ENDS. (SEE FIG. 2.)
- STEP 5. INSTALL TIE BARS AS SHOWN IN FIGS. 3 & 3A. ASSEMBLE TIE BAR BY
  INSERTING HOOKS ON EACH END OF TIE BAR INTO SLOTS IN BOTTOM FLANGE
  OF BOTH CROSS BEAMS. (SEE FIG. 3A) NOTE ALL 6 AND 8 WIDE UNITS
  MUST HAVE 2 TIE BARS INSTALLED FOR EACH PAIR OF CROSS BEAMS.
- DECKING STEEL DECKING PANELS ARE OPTIONAL EQUIPMENT. IF REQUIRED, INSTALL

  AS SHOWN IN FIG. 4. NOTE DECKING PANELS MAY BE PLACED IN RACK
  WITH SMALLER RIBS FACING EITHER UP OR DOWN. IMPORTANT RIBS IN
  DECKING PANELS MUST SPAN FROM ONE CROSS BEAM TO ANOTHER WHICH IS
  FROM FRONT TO REAR IN THE RACK.
- ADDITIONAL DECKING STRENGTH WHENEVER ADDITIONAL STRENGTH IS DESIRED ON DECKING, PLACE A 2ND LAYER OF DECKING PANELS ON TOP OF ORIGINAL LAYER OF PANELS AS SHOWN IN FIG. 6.
- FLOOR & CEILING ANCHORS (OPTIONAL) TO INSTALL, HOOK INTO RACK END UPRIGHT SLOTS SHOWN IN FIG. 5 AND FASTEN TO FLOOR OR CEILING.